



EFFICACY OF LA MOTT TOTAL CHLORINE TEST KIT #LP-3140G

***** PLEASE READ THE TEST KIT INSTRUCTIONS CAREFULLY *****

***** TO INSURE ACCURATE RESULTS, BE SURE THE POTASSIUM IODIDE SOLUTION AND THE DPD POWDER #1 HAVE REACHED THEIR EXPIRATION DATES *****

***** BOTH CHEMICALS MUST BE SECURELY SEALED AND STORED IN THE KIT BOX TO REDUCE THEIR EXPOSURE TO LIGHT AND MOISTURE *****

POTASSIUM IODIDE: THE POTASSIUM IODIDE SOLUTION TURNS TO A LIGHT YELLOW COLOR IF EXPOSED TO AIR AND MOISTURE FOR PROLONGED PERIODS OF TIME, OR IF IT EXCEEDS THE EXPIRATION DATE.

DPD POWDER #1: THE DPD POWDER #1 TURNS PINK AND TENDS TO CAKE WHEN EXPOSED TO EXCESSIVE MOISTURE OR IF IT EXCEEDS THE EXPIRATION DATE.

CONTROL TEST: TO PERFORM A CONTROL TEST, SAMPLE THE TAP WATER FOR TOTAL CHLORINE LEVELS. CALL YOUR LOCAL CITY WATER DISTRICT OFFICE TO CONFIRM THE LEVEL OF TOTAL CHLORINE IN YOUR AREA. IF THE RESULTS DIFFER, CHECK THE EXPIRATION DATES ON THE CHEMICALS.

REORDER INFORMATION: CALL 1.800.755.1707 FOR QUESTIONS OR REORDERS.

POTASSIUM IODIDE – GEM 6521G
DPD POWDER #1 - GEM 6807C